

Instruction Manual



Pitti Barista Fully Automatic Coffee Machine

Contents

1. Safety Instruction	1
2. Read before first use.....	2
3. Introduction	3
3.1 Switching on the Machine.....	3
3.2 Main User Interface	4
3.3 Espresso Setup Function	4
3.4 Americano Setup Function	4
3.5 Cappuccino Setup Function	5
3.6 Latte Setup Function	5
3.7 Dispensing Hot Water Function	6
3.8 Dispensing Hot Milk Function	6
3.9 Ground Coffee Function	6
4. Setup Menu.....	7
4.1 Setting Coffee Temperature.....	7
4.2 Brewing Unit Cleaning	8
4.3 Setting Water Hardness.....	8
4.4 Favorite Setting	9
4.5 Milk Frother System Cleaning	12
4.6 Eco Time	13
4.7 Language Selection.....	13
4.8 Cup Counter Number	14
4.9 Factory Reset.....	14
5. Warning Icons	15

1 Safety Instruction


- (1) Please read the instruction manual carefully before using the machine
- (2) Keep the machine on a stable desktop. Ensure that the machine is kept dry, ventilated and out of children's reach.
- (3) Check power specification before using the machine and connect the power according to requirement
- (4) The machine will not operate due to absence or shortage of water.
- (5) Dispose of the plastic and bubble board in the package appropriately
- (6) Keep the machine away from heat sources to avoid damaging the surface of the machine.
- (7) Normal temperature for machine usage and storage: 0°C ~ 45°C. Operating the machine beyond suggested temperature range may cause serious damage to the machine.
- (8) Add room temperature water in water canister. Hot or boiling water will damage the machine
- (9) Use a dry dishcloth to clean the machine.
- (10) Do not change the technical setup of the machine as it may result in serious damages. Manufacturer will not bear responsibility to such damages
- (11) Take out the brewing unit and wash each unit only when the machine is turned off.
- (12) Please ensure that no water is allowed inside the machine and/or near the electrical parts to avoid short circuit.
- (13) Please turn the power off and disconnect the power plug if the machine is not going to be in use for a long period of time.
- (14) Should you have any questions about the machine, kindly contact your service provider.

2 Read before first use

- (1) Please check and make sure the coffee brewing unit is inserted properly, and the waste tray and drip tray are in the right positions.
- (2) Fill the water tank with filtered, room temperature water
- (3) Pour approximately 30 grams of coffee beans into the bean container for first use./

(→ Only coffee beans should be added in the bean container. Please do not add water, coffee powder, coffee bean mixed with stones or any other hard objects as they will cause damage to the grinder.)

Voltage / Frequency	220-240VAC 50/60Hz 100-110VAC 50/60Hz	Rating Power	1200-1500 W
Water Tank Capacity	2000 ml	Bean Capacity	250 grams (without extension) 500 grams (with extension)
Pump Pressure	19 Bar (Italy ULKA pump)	Net weight	11.7 Kgs



3 Function Introduction


3.1 Switching On/Off Coffee Machine

- (1) Press the power on/off switch on the front panel. The coffee machine will start a self-test process. Please do not operate the machine during this process.
- (2) After the self-test, the coffee machine will start its heating and self-cleaning process. When completed, the main user interface will appear.


Self-test:



Heating:





Self-cleaning :




3.2 Main Function Interface





3.3 Espresso Function

(1) Press  icon to brew Espresso, users can also press icon  to stop the brewing process any time.





(Caution: the brewing unit will return to original position automatically after the coffee brewing, please do not operate any step until the brewing process completed.)


3.4 Americano Function


Press  icon to brew Coffee, users can also press icon  to stop the brewing process any time.

3.5 Cappuccino Function


(1) Press  icon, coffee machine will make Cappuccino automatically, users can also press  icon to stop the brewing process any time.

Milk Frother Process






(Remarks: During the milk frother making process, users can press icon  to stop the milk frother making process, then the coffee machine will continue to brew espresso.)

Espresso Process






3.6 Latte Function

(1) Press  icon , coffee machine will prepare Latte for your automatically, and display “Coffee Ready” when finish. Users can also press icon  to stop the brewing process any time






3.7 Hot Water Function

(1) Press  icon, coffee machine will prepare hot water automatically, users can also press  icon to stop the process any time.




3.8 Hot Milk Function

(1) Press  icon, coffee machine will prepare hot milk for you. Users can also press  icon to stop the process any time.



3.9 Ground Coffee Function


(1) Press . The following display will show 4 function selections: Espresso, Americano, Cappuccino and Latte.



- (2) Use the coffee powder spoon accessory provided with the coffee machine. Lid the right cover and pour one spoon of ground coffee into the doser.
- (3) Press the button of the required drink . The coffee taste selection interface will appear. Select the drink you desire and continue as explained in parts 3.3 to 3.6.



(→: If coffee is not added during the previous process, the coffee machine will dispense hot water only. This process will clean the brewing unit and the inner coffee tube. In addition, the coffee machine will start an automatic self-cleaning process when switched on.)

4 Setup Menu

Please press  to access the Setup Menu.




4.1 Coffee Temperature Setting

Press . The display will show a selection of temperatures: Low, Medium and High. Choose your required temperature. Press  to confirm




Low temperature: 85°C-87°C
 Medium temperature: 87°C -90°C
 High temperature: 90°C – 93°C


4.2 Brewing unit cleaning

Press  icon, the display will show Brewing unit cleaning selection:



Please choose your required , and press “  ” to confirm your selection.
The cleaning process will be carried out throughout 2 automatic cycles: Please ensure that there are 600 ml of water in the water tank
Lid the right cover and place a coffee cleaning tablet or one spoon full of coffee cleaning powder into the doser and then press OK.

4.3 Water Hardness Setting

Press  to access the descaling frequency selection. You may select any of the following levels:

- (1) Level 1: Remind you to descale after using 170L water;
- (2) Level 2: Remind you to descale after using 150L water;
- (3) Level 3: Remind you to descale after using 80L water;
- (4) Level 4: Remind you to descale after using 50L water.



Descaling your BARISTA machine :


Please fill the water container with 1 litre of fresh water with 150cc of Pitti Zerocal solution before commencing the descaling program. Please repeat the descaling process with fresh water only.
Please note: do not operate or switch off the machine until the descaling process has completed. If

don't required the descaling process, you can refuse to start it when the coffee machine reminds you.

Descaling process will be carried out throughout 2 automatic cleaning cycles: 1st time requiring one litre of fresh water and 150cc of Pitti Zerocal and 2nd time just fresh clean water (1 litre of water each time).


WARNING

Before proceeding with the descaling process, please make sure that the milk tube has been removed from the milk container



4.4 Favorite setting




Press  icon, the display will show 6 function selections for Espresso, Coffee, Cappuccino, Latte, Hot Water and Hot Milk.





ESPRESSO



(1) Press  icon the display shows espresso volume adjustment function, please press “+” or “-” icon to set required espresso volume, then press  icon to confirm setting.






AMERICANO

(2) Press  icon the display shows coffee volume adjustment function, please press “+” or “-” icon to set required coffee volume and water volume, then press  icon to confirm setting.





CAPPUCCINO


(3) Press  icon the display shows cappuccino taste adjustment function, please press “+” or “-” button to adjust the espresso volume and milk frother time, then press  icon to confirm setting.



LATTE






(4) Press  icon the display will show latte taste adjustment function , Please press “+”or “- ” button to set required **espresso volume**, **frother milk** and hot milk time, then press  icon to confirm setting.




HOT WATER






(5) Press  icon, and press “+”or “- ” button to select required hot water volume, then press  icon to confirm setting.




HOT MILK



(6) Press  icon , the display will show function select interface.

Choose  for hot milk with frother, or choose  for hot milk only.


Please press “+” or “-” icon to set required volume, press “” icon to confirm setting./





4.5 Milk Frother System Cleaning


Press  The display will remind you to put the milk tube into a container or a large cup with 1/2 litre of fresh water and 50cc (one full bottle cap) of Pitti Master Cleaning product and press  Repeat the cleaning process with fresh water only The program will last 25 seconds.

(Please ensure there is water in the water container. Insert milk tube into a cup of milk cleaning solution. Repeat cleaning process with a cup of clean water.)



4.6 Eco Time



Press . A selection of auto-off times will appear on the display. Select the desired time. Press  to confirm.




(→: Equipped with an Eco-Friendly system to save energy, the Coffee Machine will turn off automatically if it is not in use for a selected period of time. Users can also select “OFF” to cancel the auto-off function.)

4.7 Language Selection


In order to meet the use requirement from different customers and countries, we provide 4 languages for your selection.


Please press  icon, the display will show language selection interface, please select the languages according to your requirement, and press  to confirm your selection.






4.8 Cup Number Counter


Please press  to access the Setup Menu

Press . The display will show the total number of cups of Espresso/Coffee and Cappuccino/Latte made by the coffee machine. /




4.9 Factory Reset

Press  to access the factory reset interface. Press  to confirm your intention to reset the machine. Once confirmed, all configurations will be cleared from the machine. To cancel the factory reset, press .




Warning Icons


- (1) Water Shortage
Add water in water canister.



- (2) Coffee Bean Shortage
Add coffee beans in coffee bean canister.




- (3) Brewing Unit Missing
Make sure that the brewing unit is in right position and locked properly.




- (4) Waste Coffee Tray or Waste Water Tray missing
Check if these two waste trays are in the right positions.



- (5) Waste Coffee Tray Full
Empty the waste coffee tray.



- (6) Door Open
Close the side door.



- (7) Tube Blocked
Switch off the coffee machine. Make sure the water container is full and switch on the machine again.
If the problem persists, contact your service provider for assistance.

